




# Series 1100TDM

Tandem MEGALUG® Mechanical Joint Restraint

High Pressure Restraint for Ductile Iron Pipe

All EBAA products intended for installation on ductile iron pipe are designed for and limited to use on ductile iron pipes that comply with the requirements of ANSI/AWWA C151/A21.51 and have a Brinell Hardness or equivalent measurement value that does not exceed 230BHN. **These requirements apply to the entire pipe wall profile at all restraining wedge engagement points and to the full penetration depth of each restraining wedge.\***



Series 1112TDM restraining a mechanical joint fitting.

## Features and Applications:

- For use on Ductile Iron Pipe 4 inch through 54 inch
- High Pressure Restraint
- Torque Limiting Twist-Off Nuts
- Mechanical Joint follower gland incorporated into the restraint
- **MEGA-BOND®** Coating System  
For more information on MEGA-BOND, visit our web site at [www.ebaa.com](http://www.ebaa.com)
- Minimum 2 to 1 Safety Factor
- Constructed of A536 Ductile Iron
- EBAA-Seal™ Mechanical Joint Gaskets are provided with all 1100TDM MEGALUG restraints. These are required to accommodate the pressure ratings and safety factors shown.
- **New:** High strength heavy hex machine bolts with T-nuts are provided to facilitate easier assembly due to the fittings radius area prohibiting the use longer T-bolts.
- T-Nuts constructed of High Tensile Ductile Iron with Fluoropolymer Coating.

For use on water or wastewater pipelines subject to hydrostatic pressure and tested in accordance with either AWWA C600, C605 or ASTM D2774.

Nominal Pipe Size	Shipping Weights*	Post Assembly Deflection	Pressure Rating (PSI)
4	21.6	3°	700
6	33.0	3°	700
8	40.0	3°	700
10	60.2	3°	700
12	75.0	3°	700
14	112.7	2°	700
16	131.6	2°	700
18	145.2	1½°	500
20	166.6	1½°	500
24	290.2	1½°	500
30	457.9	1°	500
36	553.63	1°	500
42	1,074.8	1°	500
48	1,283.1	1°	500
54	1,445.32	½°	400

**NOTE: For applications or pressures other than those shown please contact EBAA for assistance.**

\*lbs., weights are approximate.





**EBAA IRON Sales, Inc.**  
P.O. Box 857, Eastland, TX 76448  
Tel: (254) 629-1731  
Fax: (254) 629-8931  
(800) 433-1716 within US and Canada  
[contact@ebaa.com](mailto:contact@ebaa.com)  
[www.ebaa.com](http://www.ebaa.com)

# 1100TDM Submittal Reference Drawing

EBAA IRON

MADE IN USA



Heavy Hex Bolt with T-Nut

Due to the longer bolt requirement of the 1100TDM a Heavy Hex Bolt with T-Nuts are supplied in lieu of T-bolts.

Nominal Pipe Size	Series Number	Pipe O.D.	B	M	Wedge Per Gland	Heavy Hex Head Bolt w/ T-Nut	
					Qty	Quantity	D x L
4	1104TDM	4.80	5.30	3.80	4	4	3/4 x 7
6	1106TDM	6.90	5.30	3.90	6	6	3/4 x 7
8	1108TDM	9.05	5.40	4.10	6	6	3/4 x 7
10	1110TDM	11.10	5.50	4.10	8	8	3/4 x 7
12	1112TDM	13.20	5.50	4.40	8	8	3/4 x 8
14	1114TDM	15.30	6.10	4.90	10	10	3/4 x 8
16	1116TDM	17.40	6.10	5.00	12	12	3/4 x 9
18	1118TDM	19.50	6.10	5.10	12	12	3/4 x 9
20	1120TDM	21.60	6.10	5.10	14	14	3/4 x 9
24	1124TDM	25.80	6.20	5.30	16	16	3/4 x 9
30	1130TDM	32.00	6.20	6.20	20	20	1 x 12
36	1136TDM	38.30	7.20	6.20	24	24	1 x 12
42	1142TDM	44.50	9.80	9.10	28	28	1 1/4 x 15
48	1148TDM	50.80	9.80	9.10	32	32	1 1/4 x 15
54	1154TDM	57.56	9.80	9.20	36	36	1 1/4 x 15



Note: All dimensions are in inches ± 1% and are subject to change without notice. For additional submittal dimensional data refer to the series 1100 brochure.

## Series 1100TDM Installation Instructions

1. The Series 1100TDM MEGALUG joint restraint is designed for use on ductile iron pipe conforming to ANSI/AWWA C151/A21.51 (all thickness classes) when restraining mechanical joint pipe fittings with high pressure.




All EBAA products intended for installation on ductile iron pipe are designed for and limited to use on ductile iron pipes that comply with the requirements of ANSI/AWWA C151/A21.51 and have a Brinell Hardness or equivalent measurement value that does not exceed 230BHN. **These requirements apply to the entire pipe wall profile at all restraining wedge engagement points and to the full penetration depth of each restraining wedge.\***

2. Clean the socket and the plain end. Lubrication and additional cleaning should be provided by brushing both the gasket and the plain end with soapy water or an approved pipe lubrication meeting the requirement of ANSI/AWWA C111/A21.11 just prior to slipping the gasket onto the plain end for joint assembly. [Place the secondary restraint ring labeled "1100TDM SUB (ring without a lip)" onto the pipe with the machined smooth face toward the plain end. Place the primary 1100 restraint (gland with a lip) onto the pipe with the lip facing the plain end. Place the EBAA Seal Improved Mechanical Joint Gasket onto the pipe. The EBAA Seal gasket is bi-directional and is necessary for the high-pressure rating of the assembly.]

**NOTE: In cold weather it is preferable to warm the gasket to facilitate assembly of the joint.**

3. Insert the pipe into the socket and press the gasket firmly and evenly into the gasket recess. Keep the joint straight during assembly.
4. Push the gland[s] toward the socket and center it around the pipe with the gland lip against the gasket. Insert bolts and hand tighten nuts. [Heavy Hex Head Bolts with T-Nuts have been provided for assembly because the radius of the fitting prevents installation of long t-bolts.] Make deflection after joint assembly but before tightening bolts.
5. Tighten the bolts to the normal range of torque as indicated [3-inch 45-60 ft.-lbs., 4 through 24-inch 75-90 ft.-lbs., 30 and 36-inch 100-120 ft.-lbs., and 42, 48 and 54-inch 120-150 ft.-lbs.] While at all times maintaining approximately the same distance between the gland and the face of the flange at all points around the socket. This can be accomplished by partially tightening the bottom bolt first, then top bolt, next the bolts at either side, finally the remaining bolts. Repeat the process until all bolts are within the appropriate range of torque. In large sizes (30 through 64-inch [762mm through 1,600mm]), five or more repetitions may be required. The use of a torque-indicating wrench will facilitate this procedure.

6. Tighten the torque limiting twist-off nuts in a clockwise direction (direction indicated by arrow on



top of nut) until all wedges are in firm contact with the pipe surface. Continue tightening in an alternating manner until all of the nuts have been twisted off.

7. If removal is necessary, utilize the  $\frac{5}{8}$  inch hex heads provided. If reassembly is required, assemble the joint in the same manner as above, by tightening the wedge bolts to 90 ft.-lbs. If the series 1100 restraint is removed from the pipe, be sure that all the collar bolts and wedges are in place before the restraint is reassembled.

**Steps 2-5 are requirements of AWWA Standard C600-17**

**\*To learn more about this addendum, please visit:**  
<https://ebaa.com/spec/dip>